

# Uniden®

## **XDECT 8305WP** **Waterproof Accessory Handset**

---

*For more exciting new products please visit our website:  
Australia: [www.uniden.com.au](http://www.uniden.com.au)*

---

# **OWNER'S MANUAL**

# IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- **The charger is NOT waterproof:** Do not use or place the charger near water (e.g., near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool).
- If the charger falls into the water, unplug the AC adaptor before removing it from the water.
- Wipe excess water off the handset before returning it to the charger.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- Do not place the handset in any charging cradle without the battery installed and the battery cover securely in place.

---

## ***SAVE THESE INSTRUCTIONS!***

---

### ***Important Notice:***


Under power failure conditions this appliance may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use.

### **General Notices for New Zealand Model:**

- The grant of a NZ Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- The maximum volume setting of this telephone exceeds the Telecom specified volume requirement. Telecom takes no responsibility for the high volume available on this telephone, who believe this telephone is too loud should contact the manufacturer at the website indicated on owner's manual warranty page.
- For telephone networks other than Telecom there may be a charge incurred for local calls if the Insert 0 feature is on. Turn Insert 0 off.
- This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

## XDECT 8305WP

### What's in the Box?



If any item is missing or damaged, contact your place of purchase immediately. **Never use damaged products!**

Need help? Get answers at our website:  
[www.uniden.com.au](http://www.uniden.com.au) for Australian model

### Understanding the Waterproof Handset

The handset complies with IPx7/JIS7 water submersion specifications. It can remain submerged under 1m of water for up to 30 minutes without damage or loss of functionality. If the handset falls into water, just remove it; you can continue using the handset as normal.

The handset will still receive calls even if it is under water, but you probably won't be able to hear the ringer or the earpiece. To avoid any accidents, **do not try to use the handset while it is still under water.**


If you notice that the sound is distorted after your handset is submerged in water, there might still be water around the speaker and microphone. Just shake the handset to clear the water, and the sound should return to normal. **Don't place the handset where it will be subjected to direct sunlight for long periods of time.**

# INSTALLING YOUR HANDSET

## Charge the Battery

The handset's rechargeable battery is already installed. Before you can charge the battery, you have to power it on.

1. Remove the cardboard spacer.



2. Press the power on/off (activation) pin according to the directions on the label.
3. Remove the label once the handset is powered on.  
**Save the power on/off pin in case you need to change the handset's power status later (i.e., to power off the handset when it will not be used for a long time). Use the plastic power on/off pin or a blunt-tipped object like an uncurled paper clip to press the power on/off toggle through the rubber seal. Do not use a sharp object; sharp objects might puncture the rubber seal and jeopardize the handset's waterproof status.**
4. Connect the AC adaptor to the charger's **DC IN 9V** jack and set the cord into the notch. (This adaptor might already be connected.)
5. Plug the other end of the adaptor into a standard 240V AC power outlet.
6. Place the handset in the charger with the display facing forward. The display on the handset should turn on.

If..	Try..
the handset display does not turn on	<ul style="list-style-type: none"><li>• Checking the AC adaptor connection.</li><li>• Seeing if the outlet is controlled by a wall switch.</li></ul>

 **Charge the Handset completely (16 hours) before using it.**

## Installing the Beltclip

Line up the holes on each side of the handset.

**To attach the belt clip;** Insert into the holes on each side of the handset. Press down until it clicks.

**To remove the belt clip;** Pull either side of the belt clip to release the tabs from the holes.

## REGISTERING TO A BASE

**The accessory handset won't work until you register it to a compatible Uniden cordless phone!**

### Compatible Bases

This handset is designed for use with Uniden's XDECT 8315 and XDECT 8355 bases.

Other compatible bases include Uniden's XDECT 81xx series, XDECT 6135, XDECT 5135, SSE35/37, DECT 32xx series and DECT 31xx series.

Some features may not be available when using the XDECT 8305WP with these other bases. For the most up-to-date list of which bases this handset is compatible with, see our website.

### Registration Methods

There are two different registration methods, but it's easy to figure out which one applies to your handset and base. Answer question to register the handset to one of the compatible bases.

### Does the base have an LCD display?

<b>Yes</b>	<ol style="list-style-type: none"><li>1. On the base, open the menu and select <b>Register Accy</b>. The display should show <b>Registering</b>.</li><li>2. On the handset, press and hold <b>HASH(#)</b> until the display says <b>Handset Registering</b> (about 2 seconds).</li></ol>
<b>No</b>	<ol style="list-style-type: none"><li>1. On the base, press and hold <b>FIND</b> about 5 seconds in standby mode.</li><li>2. On the handset, press and hold <b>HASH(#)</b> until the display says <b>Handset Registering</b> (about 2 seconds).</li></ol>

 **After about 30 seconds, the handset display should say *Registration Complete*.**

## Test the Connection

Pick up the handset and press **TALK/FLASH**. Make sure you get a dial tone. (Press **END** to hang up.)

If..	Try..
<ul style="list-style-type: none"><li>• you don't hear a dial tone</li><li>• the display shows <b>Registration Failed</b></li></ul>	Making sure the handset is fully charged, before trying again.

## RESETTING THE HANDSET

If you are having trouble with a handset or if you want to replace one, you need to clear the registration information from the base and the handset:

Do you have the base the HS is registered to?	
Yes	No
<ol style="list-style-type: none"><li>1. Press &amp; hold <b>END</b> and <b>#</b> until the <b>System Reset</b> menu appears (about 5 seconds).</li><li>2. Select <b>Deregister HS</b>. The display lists all registered handsets.</li><li>3. Select the HS you want to reset.</li><li>4. When the phone asks you to confirm, select <b>Yes</b>. The HS clears its information from the base &amp; deletes its own link to the base.</li></ol>	<ol style="list-style-type: none"><li>1. Press &amp; hold <b>END</b> and <b>#</b> until the <b>System Reset</b> menu appears (about 5 seconds).</li><li>2. Select <b>Base Unavailable</b>.</li><li>3. When the phone asks you to confirm, select <b>Yes</b>. The handset deletes its own link without contacting the base.</li></ol>

When you reset a handset (or if you buy a new one), that handset displays a **Handset Not Registered** message. If you see this message on a handset, you need to register it to a base before you can use it.

## IMPORTANT INFORMATION

- As the handset adapts to the base, the exact features and operation of the handset will vary slightly depending on which base you register the handset to. Refer to the owner's manual for the base you're registering the handset to for feature descriptions.
- All features and operation for the handset are described in the owner's manual for one of the bases listed under the Compatible Bases section.
- Owner's manuals for all Uniden phones are available on our website for free downloading.

### AC Adaptor

Parts Number	Input Voltage	Output Voltage
AAD-600S(R) AAD-600S(M)	100-240V AC, 50/60Hz	9V DC @ 210mA

### Battery Information

Type	Capacity	Talk time	Standby Time
BT-694	650mAh	about 12 hours	about 12 days
BT-694s	500mAh	about 10 hours	about 10 days

- Use only the supplied AC adaptors.
- Be sure to use the proper adapter for the base and any chargers.
- Do not place the power cord where it creates a trip hazard or where it could become chafed & create a fire or electrical hazard.
- Do not place the unit in direct sunlight or subject it to high temperatures.
- Fully charged, the battery should provide about 12 hours of talk time and about 12 days of standby time. For best results, return the handset to the cradle after each call to keep it fully charged.
- Keep an eye on the battery status icon. When the battery gets too low, the handset shows a low battery alert. If you hear a strange beep during a call, check the display: if you see the low battery alert, finish your conversation as quickly as possible and return the handset to the cradle. If the handset is in standby, none of the keys will operate.
- With normal use, the battery should last about one year. Replace the battery when the talk time becomes short even when the battery is charged. To buy a replacement battery, visit the website.

## **Rechargeable Nickel-Metal-Hydrate Battery Warning**

**CAUTION!** Risk of explosion if battery is replaced by an incorrect type! Dispose of used batteries according to the instructions. Do not open or mutilate the battery. Disconnect the battery before shipping this product.

- This equipment contains a rechargeable Nickel-Metal-Hydrate (Ni-MH) battery.
- Do not short-circuit the battery.
- The rechargeable battery contained in this equipment may explode if disposed in a fire.
- Do not charge the battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charger may damage the battery or cause it to explode.

Rechargeable batteries must be recycled or disposed of properly. Uniden works to reduce lead content in PVC coated cords in our products & accessories.







# ONE-YEAR LIMITED WARRANTY

## XDECT 8305WP

### Important:

Satisfactory evidence of the original purchase is required for warranty service. Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

### Warrantor:

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498 (“Uniden Aust”).

**Terms of Warranty:** Uniden Aust warrants to the original retail purchaser only that the XDECT 8305WP (“the Product”), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

**Warranty Period:** This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale. If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- A. Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner’s Manual;
- B. Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- C. Improperly installed contrary to instructions contained in the relevant Owner’s Manual
- D. Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- E. Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

**Parts Covered:** This warranty covers the Product and included accessories.

**User-generated Data:** This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images)that may be stored on your Product.

**Statement of Remedy:** If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either

repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

**Procedure for Obtaining Warranty Service:** Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden. Please refer to the Uniden website for address details. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

**UNIDEN AUSTRALIA PTY LTD**

Phone number: 1300 366 895

Email: [custservice@uniden.com.au](mailto:custservice@uniden.com.au)

**Uniden®**

©2016 Uniden Australia Pty Ltd Printed in Vietnam  
U01UU299BZB(0)